



QED Equipment Preparation Checklist

Equipment Description: Q10 Slim-line Bracket (Glass or Wall Mounting)

Customer or Reseller:		Project:
End Point Customer:		QED Project or Ticket Reference:
Step	Preparation Steps/Checks:	Completed By
		
1	Ensuring the screen protective coating is still on, carefully place the Q10 face down on a clean surface.	
2	Mark out and cut two strips of VHB tape 100 x 25mm	
		
3	Prepare the surface area of the bracket where the VHB tape is to be bonded (see above) by lightly using a gentle abrasive such as Scotchbrite and finally cleaning with Isopropanol cleaning wipes.	
4	Carefully locate one side of the VHB tape on the bracket and firmly roll thumb across to the other side to fix tape without any air pockets (caution: Tape is very difficult to remove after it has bonded so ensure it is well positioned prior to fitting). Repeat top and bottom of bracket as shown above.	
5	Finally press firmly on the tape to ensure a good bond.	
6	Place the slim-line plate hooks into the slots on the back of the screen. Slide the plate up until the bottom tab sits on the bottom face.	
7	An M3 Torx head security screw (supplied) is finally used to secure the plate to the screen through the bottom tab .	
8	For wall mounted option omit steps 3,4, 5 & 6.	
Notes: VHB tape should be applied at least 24 hrs prior to fitting the screen to a glass wall. Warmth, pressure and time all aid the bonding process.		
Issued By:		Date:
Final Shipping Approval:		Date: